

KIT CUSCINETTI E GUARNIZIONI PER STERZO (RIF. ALL-BALLS: 25-1523)

MARCA	MODELLO	CILINDRATA	ANNI	1° EQUIP.	RIF. OEM
BMW	R 45-20kw / R 45-26kw N/T	450	1978 - 1985	no	
BMW	R 65 1 ^Â a Serie	650	1978 - 1980	no	
BMW	R 65 1 ^Â a Serie	650	1978 - 1980	no	
BMW	R 65 2 ^Â a Serie	650	1980 - 1985	no	
BMW	R 65 2 ^Â a Serie	650	1980 - 1985	no	
BMW	R 65 GS	650	1987 - 1992	no	
BMW	R 65 Monolever (20KW)	650	1985 - 1987	no	
BMW	R 65 Monolever (35KW)	650	1986 - 1988	no	
BMW	R 75/5	750	1969 - 1973	no	
BMW	R 75/6	750	1973 - 1976	no	
BMW	R 75/7	750	1976 - 1977	no	
BMW	R 80 /7	800	1977 - 1978	no	
BMW	R 80 /7	800	1978 - 1980	no	
BMW	R 80 G/S Monolever	800	1980 - 1987	no	
BMW	R 80 G/S Monolever	800	1980 - 1987	no	
BMW	R 80 Monolever	800	1985 - 1985	no	
BMW	R 80 RT	800	1982 - 1984	no	
BMW	R 80 RT	800	1982 - 1984	no	
BMW	R 80 RT Monolever	800	1985 - 1985	no	
BMW	R 80 RT Monolever	800	1985 - 1985	no	
BMW	R 80 ST	800	1982 - 1985	no	
BMW	R 80 ST	800	1982 - 1985	no	
BMW	R 80/7	800	1977 - 1984	no	
BMW	R 100 CS	1000	1980 - 1980	no	
BMW	R 100 CS	1000	1980 - 1984	no	
BMW	R 100 CS	1000	1981 - 1984	no	
BMW	R 100 RS	1000	1976 - 1979	no	

BMW	R 100 RS	1000	1976 - 1984	no	
BMW	R 100 RS	1000	1980 - 1984	no	
BMW	R 100 RT	1000	1978 - 1979	no	
BMW	R 100 RT	1000	1978 - 1984	no	
BMW	R 100 RT	1000	1980 - 1984	no	
BMW	R 100 S	1000	1976 - 1980	no	
BMW	R 100/7T	1000	1978 - 1978	no	
GAS GAS	TXT PRO	200	1998 - 2001	no	
GAS GAS	TXT PRO	250	1998 - 2001	no	
GAS GAS	Contact JTX	270	1997 - 1997	no	
GAS GAS	Contact TX	270	1998 - 1998	no	
GAS GAS	TXT	280	2000 - 2001	no	
GAS GAS	TXT PRO	300	1998 - 2001	no	